


SPARE PARTS

止水環

Sealing Disk

SPARE PARTS

Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER16	12.6	2	CAP-HER16MC CAP-HER16C	ER16-HP	HER16-1 R
					HER16-1.5 R
					HER16-2 R
					HER16-2.5 R
					HER16-3 R
					HER16-3.5 R
					HER16-4 R
					HER16-4.5 R
					HER16-5 R
					HER16-5.5 R
					HER16-6 R
					HER16-6.5 R
					HER16-7 R
					HER16-7.5 R
					HER16-8 R
					HER16-8.5 R
					HER16-9 R
					HER16-9.5 R
					HER16-10 R



Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER20	15.8	2	CAP-HER20C	ER20-HP	HER20-2 R
					HER20-2.5 R
					HER20-3 R
					HER20-3.5 R
					HER20-4 R
					HER20-4.5 R
					HER20-5 R
					HER20-5.5 R
					HER20-6 R
					HER20-6.5 R
					HER20-7 R
					HER20-7.5 R
					HER20-8 R
					HER20-8.5 R
					HER20-9 R
					HER20-9.5 R
					HER20-10 R
					HER20-10.5 R
					HER20-11 R
					HER20-11.5 R
					HER20-12 R
					HER20-12.5 R
					HER20-13 R

Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER25	20.2	2	CAP-HER25C	ER25-HP	HER25-2 R
					HER25-2.5 R
					HER25-3 R
					HER25-3.5 R
					HER25-4 R
					HER25-4.5 R
					HER25-5 R
					HER25-5.5 R
					HER25-6 R
					HER25-6.5 R
					HER25-7 R
					HER25-7.5 R
					HER25-8 R
					HER25-8.5 R
					HER25-9 R
					HER25-9.5 R
					HER25-10 R
					HER25-10.5 R
					HER25-11 R
					HER25-11.5 R
					HER25-12 R
					HER25-12.5 R
					HER25-13 R
					HER25-13.5 R
					HER25-14 R
					HER25-14.5 R
					HER25-15 R
					HER25-15.5 R
					HER25-16 R

止水環 Sealing Disk

Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER32	26.2	2	CAP-HER32C	ER32-HP	HER32-2 R
					HER32-2.5 R
					HER32-3 R
					HER32-3.5 R
					HER32-4 R
					HER32-4.5 R
					HER32-5 R
					HER32-5.5 R
					HER32-6 R
					HER32-6.5 R
					HER32-7 R
					HER32-7.5 R
					HER32-8 R
					HER32-8.5 R
					HER32-9 R
					HER32-9.5 R
					HER32-10 R
					HER32-10.5 R
					HER32-11 R
					HER32-11.5 R
					HER32-12 R
					HER32-12.5 R
					HER32-13 R
					HER32-13.5 R
					HER32-14 R
					HER32-14.5 R
					HER32-15 R
					HER32-15.5 R
					HER32-16 R
					HER32-16.5 R
					HER32-17 R
					HER32-17.5 R
					HER32-18 R
					HER32-18.5 R
					HER32-19 R
					HER32-19.5 R
					HER32-20 R

Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER16	12.6	2	CAP-HER16MC CAP-HER16C	ER16-HP	HER16-1/8" R
					HER16-3/16" R
					HER16-1/4" R
					HER16-5/16" R
					HER16-3/8" R

Model	øD	L	配合螺帽	配合筒夾	訂購編號 Order No.
HER32	26.2	2	CAP-HER32C	ER32-HP	HER32-1/8" R
					HER32-3/16" R
					HER32-1/4" R
					HER32-5/16" R
					HER32-3/8" R
					HER32-1/2" R
					HER32-5/8" R
					HER32-3/4" R